



- FUNZIONI INCLUSE**
- Sensore battito cardiaco
  - Sensore pressione sangue
  - Sensore ossigeno nel sangue
  - Conteggio calorie bruciate
  - Conteggio Km percorsi
  - Sveglia con vibrazione
  - Avviso di chiamata
  - Notifica messaggi
  - Contatore di passi
  - Monitoraggio del sonno
  - Scatto remoto per selfie
  - Avviso di sedentarietà
  - Controllo musica
  - Sport (corsa, corda, addominali)
- SPECIFICHE TECNICHE**
- Schermo: a colori TFT 1.30"  
Cassa: in metallo  
Versione Bluetooth: V4.0  
Distanza di utilizzo: 8m  
Batteria: ricaricabile al Litio 150mAh  
Durata batteria in uso: 2 giorni circa  
Tempo di ricarica: 1 ora circa  
Tempo standby: 10 giorni circa  
Dimensioni: 43,6 x 35,8 x 13,1mm  
Resistenza all'acqua: IP65  
Peso: 46gr
- CONSIGLI DI UTILIZZO**
- Tenere il dispositivo lontano da fonti di calore e luce solare diretta. Tenere lontano dalle fiamme.
  - Non esporre a temperature estreme (-10°/+60°).
  - Non ricaricare la batteria con temperature - 0° o +45°.
  - Non immergere nell'acqua e non smontare.

SCHERMATE DEL DISPOSITIVO	
ORA/DATA/STATO CARICA BATTERIA	
PASSI E CALORIE CONSUMATE	
MONITORAGGIO BATTITO CARDIACO/PRESSIONE / OSSIGENO	ATTENZIONE: la misurazione è indicativa. Il prodotto non è un dispositivo medico.
Tenere premuto per avviare la misurazione	
SPORT	
Tenere premuto per accedere al sotto menù e scegliere l'attività	
CORSA Tenere premuto per avviare il timer	
SALTO DELLA CORDA Tenere premuto per avviare il timer	
ADDOMINALI Tenere premuto per avviare il timer	
MESSAGGI	
Tenere premuto per visualizzare le notifiche ricevute	
ALTRO	
Tenere premuto per accedere al sotto menù:	
SONNO Tenere premuto per avviare il timer	
MUSICA	
Tenere premuto per accedere. Premere una volta per scegliere il pulsante. Tenere premuto per selezionarlo.	
SCATTO REMOTO FOTOCAMERA	
Tenere premuto 3 secondi e aprire l'App FitPro	
TROVA TELEFONO	
Tenere premuto per far suonare lo smartphone	
FORMATTA	
Tenere premuto per ripristinare il dispositivo	
SPEGNIMENTO	
Tenere premuto 3 secondi per spegnere il dispositivo	

**RICARICA DELLA BATTERIA**  
Prima ricarica: mantenere il dispositivo collegato alla corrente fino a carica completa.

Prendere il caricatore a clip dello smartwatch (incluso nella confezione) e far combaciare i connettori del dispositivo con quelli del caricatore. In seguito collegare il caricatore ad una presa USB ed alla corrente elettrica. Il dispositivo indicherà sullo schermo lo stato di carica della batteria. Consigliamo di non ricaricare tramite un computer ma direttamente dalla corrente elettrica.

**ACCENSIONE/SPEGNIMENTO/STANDBY**


Premere 3 secondi il pulsante tattile per accendere. Per spegnere premere il pulsante fino a visualizzare la schermata **MORE**, tenere premuto per accedere al sottomenù e premere fino a visualizzare la schermata **OFF**. Tenere premuto il pulsante 3 secondi per spegnere. Il dispositivo entra in standby automaticamente dopo qualche secondo di inutilizzo.

**PASSARE DA UNA SCHERMATA ALL'ALTRA**

Utilizzare il pulsante tattile sullo smartwatch, per passare da una schermata all'altra. Tenere premuto 3 secondi per visualizzare il sottomenù (dove è segnalato), altre informazioni/attivare la funzione (NB. non è disponibile per tutte le funzioni).

**REGOLARE DATA E ORA**  
La regolazione di data e ora avviene automaticamente in seguito all'associazione tra dispositivo e smartphone.

**DOWNLOAD APPLICAZIONE**  
Scarica sul tuo smartphone l'applicazione "FitPro" da Google Play Store o App Store e installala sul tuo smartphone.



Scarica FitPro

Per effettuare correttamente la connessione tra smartphone e dispositivo, ti consigliamo di seguire attentamente la procedura riportata in seguito. In caso di problemi, cancellare l'applicazione, dissociare il dispositivo Bluetooth dalle impostazioni dello smartphone e ripetere l'operazione dall'inizio.

**ASSOCIAZIONE BLUETOOTH TRA SMARTWATCH E SMARTPHONE**

- 1- Assicurati di avere il Bluetooth acceso sul tuo dispositivo ma non effettuare l'associazione dei due dispositivi dalle impostazioni Bluetooth.
- 2- Accendi lo SmartWATCH
- 3- Apri l'applicazione "FitPro", acconsenti a tutti i pop up che verranno proposti. Puoi scegliere se iscriverti o saltare la registrazione. Se la connessione tra applicazione e dispositivo non avviene automaticamente, clicca in basso sull'icona **DISPOSITIVO**, **ASSOCIA DISPOSITIVO**.
- 4- In questo modo viene avviata la ricerca dei dispositivi;
- 5- Ora seleziona il dispositivo trovato: "BJWATCH4";
- 6- Consenti l'abbinamento Bluetooth e la sincronizzazione con l'applicazione. Ora lo smartwatch è collegato correttamente.

**DOWNLOAD APPLICAZIONE**  
Scarica sul tuo smartphone l'applicazione "FitPro" da Google Play Store o App Store e installala sul tuo smartphone.



Scarica FitPro

**ASSOCIAZIONE BLUETOOTH TRA SMARTWATCH E SMARTPHONE**

- 1- Assicurati di avere il Bluetooth acceso sul tuo dispositivo ma non effettuare l'associazione dei due dispositivi dalle impostazioni Bluetooth.
- 2- Accendi lo SmartWATCH
- 3- Apri l'applicazione "FitPro", acconsenti a tutti i pop up che verranno proposti. Puoi scegliere se iscriverti o saltare la registrazione. Se la connessione tra applicazione e dispositivo non avviene automaticamente, clicca in basso sull'icona **DISPOSITIVO**, **ASSOCIA DISPOSITIVO**.
- 4- In questo modo viene avviata la ricerca dei dispositivi;
- 5- Ora seleziona il dispositivo trovato: "BJWATCH4";
- 6- Consenti l'abbinamento Bluetooth e la sincronizzazione con l'applicazione. Ora lo smartwatch è collegato correttamente.

OPEN SPACE S.R.L. | Via A.Massarenti, 18 - MILANO (MI)

MADE IN P.R.C.    

**Smart**  
WATCH 4  
USER GUIDE EN

**1- Charging connector**  
**2- Sensor**  
**3- Color digital screen**  
**4- Touch button**

**PACKAGE CONTENTS**  
1 Smartwatch, 2 straps, 1 charger, 1 user guide

**FEATURES INCLUDED**

- Heart rate sensor
- Blood pressure sensor
- Blood oxygen sensor
- Calories burned count
- Distance count
- Alarm clock with vibration
- Call notification
- Message notification
- Step counter
- Sleep monitoring
- Remote selfie shooting
- Sedentary notification
- Music control
- Sports (running, skipping, situp)

**TECHNICAL SPECIFICATIONS**

Screen: color TFT 1.30"  
Watch case: metal  
Bluetooth Version: V4.0  
Distance of use: 8m  
Battery: rechargeable lithium 150mAh  
Working time: about 2 days  
Charging time: about 1 hour  
Standby time: about 10 days  
Size: 43,6 x 35,8 x 13,1mm  
Water resistance: IP65  
Weight: 46gr

**RECOMMENDATIONS FOR USE**

- Keep the device away from heat sources and direct sunlight. Keep away from flames.
- Do not expose to extreme temperatures (-10°/+60°).
- Do not recharge the battery in temperatures -0° or + 45°.
- Do not immerse in water and do not disassemble.

DEVICE SCREENS	
HOUR/DATE/BATTERY CHARGE STATUS	
STEPS AND CALORIES CONSUMED	
HEART / PRESSURE / OXYGEN MONITORING	ATTENTION: the measurement is indicative. The product is not a medical device.
Press and hold to start measurement	
SPORT (SPORTS)	
Press and hold to access the submenu and choose the activity	
RUN Press and hold to start the timer	
ROPE SKIPPING Press and hold to start the timer	
SITUPS Press and hold to start the timer	
MESSAGGI (MESSAGES)	
Press and hold to view received notifications	
ALTRO (OTHER)	
Press and hold to access the submenu:	
SONNO (SLEEP) Press and hold to start the timer	
MUSICA (MUSIC)	
Press and hold to enter. Press once to choose the button. Press and hold to select it.	
SCATTO REMOTO (REMOTE CAMERA SHUTTER)	
Hold down for 3 seconds and open the FitPro App	
TROVA TELEFONO (FIND SMARTPHONE)	
Press and hold to make the smartphone ring	
FORMATTA (RESET)	
Press and hold to reset the device	
SHUTDOWN	
Press and hold 3 seconds to turn off the device	

**HOW TO CHARGE**  
First charging: keep the device plugged in until fully charged.

Take the smartwatch clip charger (included in the package) and match the connectors of the device with those of the charger. Then connect the charger to a USB charger and to the power supply. The device will indicate the battery charge status on the screen. We recommend not charging by computer but directly from the electricity.

**ON / OFF / STANDBY**

Press the touch button for 3 seconds to turn on. To turn off, press the button until the **OTHERS** screen is displayed, keep pressed to access the submenu and press until the **SHUT DOWN** screen is displayed. Press and hold the button 3 seconds to turn off. The device goes into standby automatically after a few seconds of inactivity.

**SWITCH FROM ONE SCREEN TO ANOTHER**

Use the touch button on the smartwatch to switch from one screen to another. Press and hold for 3 seconds to display the submenu (where it is indicated), other information / activate the function (Note: it is not available for all functions).

**ADJUST DATE AND TIME**  
The date and time are adjusted automatically following the association between the device and smartphone.

**DOWNLOAD APP**  
Download the "FitPro" application from Google Play Store or App Store and install it on your smartphone.



Download FitPro

To make the connection between smartphone and device correctly, we recommend that you follow the steps below carefully. In case of problems, delete the application, disconnect the Bluetooth device from the smartphone settings and repeat the operation from the beginning.

**BLUETOOTH ASSOCIATION BETWEEN SMARTWATCH AND SMARTPHONE**

- 1- Make sure you have Bluetooth access on your device but do not pair the two devices from the Bluetooth settings.
- 2- Turn on the SmartWATCH
- 3- Open the "FitPro" application, consent to all the pop-ups that will be proposed. You can choose whether to subscribe or skip the registration. If the connection between application and device does not occur automatically, click on the **DEVICE** icon, **PAIR DEVICE** at the bottom.
- 4- This starts the devices search;
- 5- Now select the founded device: "BJWATCH4";
- 6- Allow Bluetooth pairing and synchronization with the application. The smartwatch is now connected correctly.

**WARRANTY**  
This product is covered by the two-year warranty provided by the Consumer Code Legislative Decree n. 206 of 6 September 2005). The warranty is not applicable in the event of damage caused by accidents, misuse and tampering by the customer on the product and does not cover normal wear and tear of all accessories and the built-in battery.

**DISPOSAL**  
Directive 2012/19 / EU (Waste electrical and electronic equipment - WEEE): information for users. This product complies with Directive 2012/19 / EU. The crossed-out bin symbol shown on the appliance indicates that the product at the end of its useful life must be treated separately from household waste. The user is responsible for the transfer of the device, at the end of its life, to its own collection facilities. Adequate separate collection for the subsequent forwarding of the decommissioned appliance for recycling, treatment and environmentally compatible disposal, helps to avoid possible negative effects on the environment and on its health and favors the recycling of the materials of which the product is made. For more detailed information regarding the collection systems available, contact the local waste disposal service or the shop where the purchase was made.

The rechargeable battery contained in the device must be disposed of separately in the special bins for the collection of exhausted batteries. Do not dispose of the product in the environment.

The manufacturer, OPEN SPACE SRL, declares that the BJ-WATCH4 type of radio equipment complies with directive 2014/53 / EU. The full text of the EU declaration of conformity is available at the following Internet address: <http://www.coverbijoux.com/dichiarazioni-conformita/>

OPEN SPACE S.R.L. | Via A.Massarenti, 18 - MILANO (MI)

MADE IN P.R.C.    